Scan 80 - Spare Parts



High Top, complete
51053138 (Black)
51053782 (White)



High Top for corner instal., complete
51053140 (Black)
51053783 (White)



Cover for top outlet
51053201 (Black)
51053785 (White)

Heat accumulation stones
51049926



Low top
51053200 (black)
51053781 (white)



Burn plate kit, complete
51053154



Inside, outlet connection piece
51053167



Screws for
outlet pieces
51053238

Outside, outlet connection piece
51053207



Rear cover, complete
51053179 (Black)
51053787 (White)



Gasket for flue outlet
51046849



Cover for flue outlet
51046855

Door, Complete
51053236

Inside cover for burnchamber kit
51053212



Vertical cover kit, left
51053160

Glass Gasket
AL
51053223

Screw kit
51053327

Top door list kit
51053183

Baffle unit
51053215

Bauart kit
51053157



Guide for baffle unit
51053210

Glass list, top or bottom
51053185

Door gasket (2,7 m.)
AM
51053187

Hook
Incl. Pinol screw
50006110

Cast Iron grate
51053148

Ash drawer
51053026



Gasket for cast
iron bottom
51050570



Secondary air handle
51053159



Primary air handle
51053158



Cast iron bottom
51053147

Front glass kit
51053145

Vertical cover, Kit, Right
51053166

Closing mechanism kit
51053186

Glass list, top or Bottom
51053185

Shaft + Pin, kit
51053231

Bottom door list, kit
51053184

Door trim, left
51053234

Door handle, kit
51053216

Door trim, center
51053235

Push out mechanism, kit
51053213

Closed base, complete
51053156 (Black)
51053784 (White)



Base with door, complete
51053155



Door for base
Incl. Hinges
51053237

Adjustment screws kit
M8x30
51046856



Small floor plate
Clear glass: 50052370
Smoked glass: 50052364



Large floor plate
Clear glass: 50052372
Smoked glass: 50052371